




Item	Part number	Description	Quantity
1	PPG20-25	SPLIT UPPER RACK	2
2	PPG20-2	MAIN RACK	1
3	PPG20-4	DRIP TRAY	1
4	PPG20-5	HEAT DEFLECTOR	1
5	PPG20-8	SLIDE GRILL ROD	1
6	PG24-9	PULLOUT KNOB	2
7	PPG20-3	GRILL LID	1
8	PPG20-7	UPPER RACK BRACKET	2
9	PPG20-14	DRIP SUPPORT ROD	1
10	PPG20-16	SLIDE SUPPORT ROD	2
11	PPG20-12	BURNER PULLOUT	1
12	PG24-11	GREASE BUCKET	1
13	PPG20-15	STRAIGHT LEG ASSEMBLY	1
14	PPG20-18	WHEEL AXLE	2
15	PG24-16	WHEEL	2
16	PPG20-13	BURN CUP	1
17	PG24-21	HOT ROD	1
18	PG24-17	ASH CUP	1
19	PG24-57	HANDLE	1
20	PG24-59	M6 HANDLE SCREW	2
21	PG24-71	HANDLE BEZEL	2
22	PPG20-6	HANDLE DEFLECTOR	1
23	PG24LS-8	LID HINGE	2
24	PG24-54	PROBE COVER	1
25	PG24-44	RTD	1
26	ATS-4	LATCH	3
27	PPG20-29	HOPPER ASSEMBLY (NO WIFI)	1
	PPG20-29WF	HOPPER ASSEMBLY (WIFI)	0
28	PPG20-9	HOPPER GASKET	1
29	TS90-1	SNAP BUTTON	5
30	PPG20-26	LEG PLUG	2
31	PPG20-11	REAR BENT LEG ASSEMBLY	1
32	PPG20-17	PULL HANDLE	1
33	LEGXS	LEG LEVELER	2
34	PPG20-10	FRONT BENT LEG ASSEMBLY	1



Item	Part number	Description	Quantity
1	PPG20-19	HOPPER LID	1
2	PPG20-20	AUGER GUARD	1
3	SS50T	LATCH	1
4	PGC24-12	HOPPER HANDLE	1
5	PPG20-21	HOPPER SIDE	1
6	PG24-26	FAN	1
7	PG24-24	AUGER MOTOR WITH IMPELLEF	1
8	PG24-48	POWER CORD	1
9	PG24SGC-3	CONTROLLER KNOB	1
10	PPG20-28	CONTROLLER (NO WIFI)	1
	PPG20-28WF	CONTROLLER (WIFI)	0
11	PG24-89B	MEAT PROBE (BLACK)	1
	PG24-89R	MEAT PROBE (RED)	1
12	BTOP-1	BOTTLE OPENER	1
13	PPG20-23	AUGER	1
14	PG24-23	AUGER BUSHING	1
15	PG24-25	SHEAR PIN WITH NUT	1





SEE DETAIL E




DETAIL E
SCALE 0.150








SEE DETAIL B




SEE DETAIL C











DETAIL D
SCALE 0.250















SCALE 0.150



SCALE 0.150

