


TB90LWG-2 PARTS LIST



POSITION	PARTS	DESCRIPTION	QUANTITY
1	SG90	GRIDDLE	1
2	GCH10	GREASE CUP HOLDER	1
3	WS90-P	WINDSCREEN	1
4	1095	GRATE	1
5	0808	BURNER	3
6	0826L	AIR VENT	3
7	0980	SPRING	3
8	0997	VALVE	3
9	KN08-1	KNOB	3
10	GBIGN1	ELECTRODE LEFT AND MIDDLE	2
11	GBIGN2	ELECTRODE RIGHT	1
12	GB-3	MANIFOLD	1
13	TS90-4	DEFLECTOR	1
14	YK01	GRATE HOOK	1
15	YK02	THUMB SCREW	1
16	0789-HEX	#8 SCREW	3
17	1046HDB	HOLD DOWN BRACKET	1
18	PTH	TOWEL HOLDER	1
19	TH-5	UTINSEL RACK	1
20	330076	THUMB SCREW	4
21	104615	LEG EXTENSION	4
22	HRL	LOW PRESSURE REGULATOR	1
23	097110	1.25" LEG PLUG	8
24	GB-6	ROTARY COVER	1
25	GB-4	3 PRONG IGNITER	1
26	GB-5	ROTARY KNOB	1