


How to take off the bottom panel in the new hopper



Warning: Before you begin make sure the item is unplugged from the power source.



To take the bottom panel off the hopper, unscrew the 4 screws on the bottom of the hopper.



Then take out the 3 screws on the left side of the hopper. At the bottom of the side panel.



Please note that when installing the bottom panel back into place, you will want to make sure this lip is tucked inside the panel before tightening your screws on the bottom.

If you have any questions, please
contact our customer service
department.

Our agents will be happy to help.
They are available at 1-800-650-2433
Mon-Fri, 7 am - 5 pm, MST

Note: The Manufacturer is not liable for any replacement parts, equipment, and/or injury due to improper installation or modification.