How to change out the burner in the PGSEAR



<u>Warning</u>: Before you begin make sure the item is removed from the propane tank. Remove the grill grate, flavor screen and heat deflector so that you have access to the burner.





It is connected by this 1 screw. Once you take out the screw, the burner will pull out from the valve.



When you install the new burner, make sure the end of the valve is inserted into the burner tube so that the gas goes up into the burner. Then go ahead and screw the burner into place.



If after troubleshooting with this manual, if you are still experiencing problems, please contact out customer service department. Our agents will be happy to help. You can contact them at 1-800-650-2433

Note: The Manufacture is not liable for any replacement parts, equipment, and/or injury due to improper installation or modification.