





PG24SSG-1 PARTS

Item	Part Number	Description	Quantity
1	PG24-11	GREASE BUCKET	1
2	PG24-16	WHEEL	2
3	PG24-17	ASH CUP	1
4	PG24-34	FEED GASKET	1
5	PG24-41	BURNER PULLOUT	1
6	PG24-42	PULLOUT LOCK	1
7	PG24-44	THERMOMETER	1
8	PG24-5	CHIMNEY CAP ASSEMBLY	1
9	PG24-54	PROBE COVER	1
10	PG24-57	HANDLE	1
11	PG24-59	HANDLE M6 BOLT	2
12	PG24-70	COOKING GRATE	2
13	PG24-71	HANDLE BEZEL	2
Not Shown	PG24-72	HARDWARE KIT	1
14	PG24-79	CHIMNEY HARDWARE KIT	1
15	PG24-84H	CHIMNEY	1
16	PG24-85	CHIMNEY GASKET	1
17	PG24-9	KNOB	3
18	PG24LS-8	HINGE ASSEMBLY	2
19	PG24SG-1	SLIDE ROD	2
20	PG24SG-12	HANDLE DEFLECTOR	1
21	PG24SG-3	PULL ROD	1
22	PG24SG-5	UPPER GRATE	2
23	PG24SG-6	GRILL LID (BLACK)	1
24	PG24SSG-1	LOUVERED DRIP TRAY	1
25	PG24SSG-2	HEAT DEFLECTOR	1
26	PG24SSG-5	LEG SKIRT	2
27	PG24SSG-6	SILICONE WASHER	12
28	PG24SSG-7	LEG BOLT CAP	12
29	PG24VWSB-31	UPPER GRATE BRACKET	2
30	PG24VWSB-33	HOPPER ASSEMBLY WIFI	1
31	PG24XT-1	LEFT LEG	2
32	PG24XT-2	RIGHT LEG	2
33	PG24XT-3	AXLE BOLT	2
34	PG24XT-4	AXLE	1
35	PG24ZG-6	SHELF (BLACK)	1
36	PG36SGX0-1	COVER PLATE	1

PG24SSG HOPPER ASSEMBLY



Article Numéro de pièce		Description	Quantité
1	BTOP-1	BOTTLE OPENER	1
2	PG24-21	HOT ROD	1
3	PG24-23	AUGER BUSHING	1
4	PG24-24	AUGER MOTOR	1
5	PG24-25	SHEAR PIN WITH NUT	1
6	PG24-26	FAN	1
7	PG24-27	FAN IMPELLER	1
8	PG24-42	PULLOUT LOCK	1
9	PG24-48	POWER CORD	1
10	PG24-49	AUGER IMPELLER	1
11	PG24-78	BURN CUP	1
12	PG24-89B	MEAT PROBE BLACK	1
	PG24-89G	MEAT PROBE GREY	1
	PG24-89R	MEAT PROBE RED	1
	PG24-89U	MEAT PROBE BLUE	1
13	PG24-9	KNOB	1
14	PG24CL-10	CONTROLLER KNOB	1
15	PG24CL-3	HOPPER LID BLACK	1
16	PG24CL-4	AUGER GUARD	1
17	PG24CL-6	HOPPER WINDOW ASSEMBLY	1
18	PG24CL-8	HOPPER CLEANOUT	1
19	PG24SSG-4	GUARD PLATE	1
20	PG24VWSB-1	CONTROLLER WITH WFI	1
21	PG24VWSB-36	HOPPER ATTACHMENT BKT.	1
22	PGC24-12	HOPPER HANDLE	1
23	PGC24-18	LID MAGNET	1
24	PGC24-8	AUGER	1